

Week10

Teacher: 廖裕評 Yu-Ping Liao

TA: 陳大荃 Da-chuan Chen, 陳恩妮 En-ni Chen

#### Class Rules

- 1. No drink besides water.
- 2. Bring a laptop and breadboard if needed.
- 3. Ask us TAs to sign and borrow development boards. Do not sign or ask others to sign for you without TAs' permission.
- 4. Arriving 10 minutes after the bell rings will be regarded as absent.
- 5. If you damage any borrowed equipment, you have to pay for it.

#### **Homework Rules**

- 1. Includes: A. Class content, B. Class exercise, C. Homework (screenshot or video)
- 2. Editing software: MS PowerPoint
- 3. File format: PDF
- 4. Filename: "date\_group\_studentID\_name.pdf", like "0916\_第1組\_11028XXX\_陳OO.pdf"
- 5. The homework deadline is 23:59 of the day before the next class. If you are late, then your grade will be deducted.

#### **Contact**


If you encounter any problems with this class, please get in touch with us with the following E-mails:

- 1. Teacher, Prof. Yu-Ping Liao 廖裕評: <a href="mailto:lyp@cycu.org.tw">lyp@cycu.org.tw</a>
- 2. TA, Da-chuan Chen 陳大荃: <u>dachuan516@gmail.com</u>
- 3. TA, En-ni Chen 陳恩妮: anna7125867@gmail.com

Or visit 篤信 Lab353 for further questions.

#### Outline of the Week

- 1. UART introduction
- 2. UART Project.
- 3. Homework 10-1.
- 4. Homework 10-2.
- 5. Homework 10-3(Bonus).




#### What is UART?

- Universal Asynchronous Receiver Transmitter (UART) is a computer hardware device for asynchronous serial communication in which the data format and transmission speeds are configurable. Two common signal levels are RS-232.
- UART vs USART:
- UART(Universal Asynchronous Receiver Transmitter): Not Synchronous
- USART(Universal Synchronous Asynchronous Receiver Transmitter): Synchronous

#### How to transmit?

- URx\_RX: Receive data(Input)
- Urx\_TX: Send data(Output)



## Send signal:

- Start bit: 1bit low potential.
- Word length: 7, 8, or 9-bit
- Stop bit: 1 or 2 bit high potential
- Parity: Even, odd, or no-parity bit generation and detection






Figure 172. UART Serial Data Format

## example



ASCII code: H=DEC 72 => Binary 01001000

i = DEC 105=> Binary 01101001



## Open project

Path:"~/HT32\_STD\_5xxxx\_FWLib\_V1.5.1\_7084/example/USART/Interrupt/MDK\_ARMv537".



#### int main

```
69 int main (void)
70 □ {
      HT32F DVB LEDInit (HT LED1);
71
      HT32F DVB LEDInit(HT_LED2);
72
73
      gURRx Ptr = gRx Buffer;
74
75
      UxART Configuration();
76
                                                 → UART Configure
77
      UxART TxTest();
78
                                                 → UART write test
79
80
      while (1)
81 =
         UxART RxTest();
82
                                                 → UART read test
83
84
85
```

## UxART\_Configuration

```
void UxART Configuration(void)
 91 □ {
       #if 0 // Use following function to configure the IP clock speed.
 93
       // The UxART IP clock speed must be faster 16x then the baudrate.
 94
       CKCU SetPeripPrescaler(CKCU PCLK UxARTn, CKCU APBCLKPRE DIV2);
 95
       #endif
 96
 97
       { /* Enable peripheral clock of AFIO, UxART
 98
         CKCU PeripClockConfig TypeDef CKCUClock = {{0}};
         CKCUClock.Bit.AFIO
                                                                                 → CKCU Configure
100
         CKCUClock.Bit.HTCFG UART RX GPIO CLK = 1;
         CKCUClock.Bit.HTCFG UART IPN
101
         CKCU PeripClockConfig(CKCUClock, ENABLE);
102
103
104
105
       /* Turn on UxART Rx internal pull up resistor to prevent unknow state
106
       GPIO PullResistorConfig(HTCFG UART RX GPIO PORT, HTCFG UART RX GPIO PIN, GPIO PR UP);
                                                                                                    set pull-up resistor
107
108
       /* Config AFIO mode as UxART function.
109
       AFIO GPxConfig(HTCFG UART TX GPIO ID, HTCFG UART TX AFIO PIN, AFIO FUN USART UART);
                                                                                                    Pin Configure
       AFIO GPxConfig(HTCFG UART RX GPIO ID, HTCFG UART RX AFIO PIN, AFIO FUN USART UART);
110
111
```

## UxART\_Configuration

```
120 🖹
         /* III NOTICE III
121
            Notice that the local variable (structure) did not have an initial value.
122
            Please confirm that there are no missing members in the parameter settings below in this function.
123
         USART InitTypeDef USART InitStructure = {0};
124
         USART InitStructure.USART BaudRate = 115200;
125
         USART_InitStructure.USART_WordLength = USART_WORDLENGTH_8B;
126
127
         USART InitStructure.USART StopBits = USART STOPBITS 1;
                                                                                   → Set up USART transmission format.
128
         USART_InitStructure.USART_Parity = USART_PARITY_NO;
         USART InitStructure.USART Mode = USART MODE NORMAL;
129
         USART Init (HTCFG UART PORT, &USART InitStructure);
130
131
132
133
       /* Enable UxART interrupt of NVIC
       NVIC EnableIRQ(HTCFG_UART_IRQn);
134
135
136
                                                                                   → Enable Rx interrupt
137
       USART IntConfig(HTCFG UART PORT, USART INT RXDR, ENABLE);
138
139
       /* Enable UxART Tx and Rx function
140
       USART TxCmd(HTCFG UART PORT, ENABLE);
141
       USART RxCmd (HTCFG UART PORT, ENABLE);
142
```

## UxART\_TxTest

```
void UxART TxTest(void)
149 □ {
                                                               → Change the Tx transmission completion status to FALSE.
       gIsTxFinished = FALSE;
150
151
       gURTx Ptr = (u8 *)gHelloString;
                                                                           → Set up the transmission data and data length.
152
       gURTx Length = sizeof(gHelloString) - 1;
       USART IntConfig(HTCFG UART PORT, USART INT TXDE
                                                          USART INT TXC, ENABLE);
153
                                                                                     → Enable Tx interrupt
154
155
                                       // Latest byte move to UxART shift register, but the transmission may be on going.
       while (gURTx Length != 0);
       while (gIsTxFinished == FALSE); // Set by TXC interrupt, transmission is finished.
156
157
```

### UxART\_RxTest


```
void UxART RxTest (void)
164 - {
165
       u32 i;
       u32 uLength;
166
167
       /* Waiting for receive 5 data
168
169
       if (gURRx Length >= 5)
                                                      → When the length of the received data is greater than or equal to 5.
170 =
171
         // Process Rx data by gRx Buffer[] and gURRx Length here
172
         // ....
173
174
         uLength = gURRx Length;
175
         for (i = 0; i < uLength; i++)
176
                                                                         → Put the received data into the Tx buffer.
177
           gTx Buffer[i] = gRx Buffer[i];
178
179
180 =
         #if 1 // Loop back Rx data to Tx for test
         gIsTxFinished = FALSE;
181
                                                                                           Trigger the Tx interrupt to
         gURTx Ptr = gTx Buffer;
182
         gURTx Length = uLength;
183
                                                                                           transmit data.
184
         USART IntConfig(HTCFG UART PORT, USART INT TXDE
                                                             USART INT TXC, ENABLE);
185
         #endif
186
187
         gURRx Length = 0;
188
189
```




Experiment/blob/main/w10/USART-Interrupt-Experiment\_Steps.md

## Execute the example and explain the code

- Objective: Display data when received exactly or more than 5 characters.
- Hint:
- 1. Check the jumper and serial port.
- 2. Do not use RETARGET\_Configuration() function.
- 3. If failed, check Tera Term settings: character encoding, local echo, and baudrate.



☆ PS. Please record.



#### Observe the waveform of the characters.

- Objective: Send two characters and observe the waveform.
- Hint:
- 1. Wire: Tx -> oscilloscope(RED) / GND -> oscilloscope(BLACK)
- 2. Edit code:


```
void UxART_RxTest(void)
{
    u32 i;
    u32 uLength;

    /* Waiting for receive 5 data
    if (gURRx_Length >= 1)
    {
        // Process Rx data by gRx_Buffer[] and gURRx_Length here
        // ....

    uLength = gURRx_Length;

    for (i = 0; i < uLength; i++)
        {
            gTx_Buffer[i] = gRx_Buffer[i];
        }
}</pre>
```


☆ PS. Please take a picture and explain the result.



#### 二進位、八進位、十進位、十六進位轉換

| - +進位                                       | 轉換 | 二進位 ———————————————————————————————————— | 轉換 |
|---|----|--|----|
| - 十六進位 ———————————————————————————————————— | 轉換 | 八進位 ———————————————————————————————————— | 轉換 |

|          | ASCII printable characters |         |          |            |         |                     |            |         |  |  |  |
|----------|----------------------------|---------|----------|------------|---------|---------------------|------------|---------|--|--|--|
| DEC      | HEX                        | Simbolo | DEC      | HEX        | Simbolo | DEC                 | HEX        | Simbolo |  |  |  |
| 32       | 20h                        | espacio | 64       | 40h        | @       | 96                  | 60h        | •       |  |  |  |
| 33       | 21h                        | 1       | 65       | 41h        | Ă       | 97                  | 61h        | а       |  |  |  |
| 34       | 22h                        |         | 66       | 42h        | В       | 98                  | 62h        | b       |  |  |  |
| 35       | 23h                        | #       | 67       | 43h        | С       | 99                  | 63h        | C       |  |  |  |
| 36       | 24h                        | \$      | 68       | 44h        | D       | 100                 | 64h        | d       |  |  |  |
| 37       | 25h                        | %       | 69       | 45h        | E       | 101                 | 65h        | е       |  |  |  |
| 38       | 26h                        | &       | 70       | 46h        | F       | 102                 | 66h        | f       |  |  |  |
| 39       | 27h                        |         | 71       | 47h        | G       | 103                 | 67h        | g       |  |  |  |
| 40       | 28h                        | (       | 72       | 48h        | H       | 104                 | 68h        | h       |  |  |  |
| 41       | 29h                        | )       | 73       | 49h        | ı,      | 105                 | 69h        | į       |  |  |  |
| 42       | 2Ah                        |         | 74       | 4Ah        | J       | 106                 | 6Ah        | j       |  |  |  |
| 43       | 2Bh                        | +       | 75       | 4Bh        | K       | 107                 | 6Bh        | k       |  |  |  |
| 44       | 2Ch                        | ,       | 76       | 4Ch        | L       | 108                 | 6Ch        | ı       |  |  |  |
| 45       | 2Dh                        | -       | 77       | 4Dh        | M       | 109                 | 6Dh        | m       |  |  |  |
| 46       | 2Eh                        | ;       | 78       | 4Eh        | N       | 110                 | 6Eh        | n       |  |  |  |
| 47<br>48 | 2Fh                        | /       | 79       | 4Fh        | 0       | 111                 | 6Fh        | 0       |  |  |  |
| 48<br>49 | 30h<br>31h                 | 0       | 80<br>81 | 50h<br>51h | P       | 112<br>113          | 70h<br>71h | p       |  |  |  |
| 50       | 32h                        | 1<br>2  | 82       | 52h        | Q       | 113                 | 72h        | q       |  |  |  |
| 51       | 33h                        | 3       | 83       | 53h        | R<br>S  | 115                 | 73h        | r       |  |  |  |
| 52       | 34h                        | 3<br>4  | 84       | 54h        | S<br>T  | 116                 | 74h        | s<br>t  |  |  |  |
| 53       | 35h                        | 5       | 85       | 55h        | Ú       | 117                 | 75h        | -       |  |  |  |
| 54       | 36h                        | 6       | 86       | 56h        | V       | 118                 | 76h        | u<br>v  |  |  |  |
| 55       | 37h                        | 7       | 87       | 57h        | w       | 119                 | 77h        | w       |  |  |  |
| 56       | 38h                        | 8       | 88       | 58h        | X       | 120                 | 78h        | X       |  |  |  |
| 57       | 39h                        | 9       | 89       | 59h        | Ŷ       | 121                 | 79h        |         |  |  |  |
| 58       | 3Ah                        |         | 90       | 5Ah        | Ž       | 122                 | 7Ah        | y<br>z  |  |  |  |
| 59       | 3Bh                        | ;       | 91       | 5Bh        | [       | 123                 | 78h        | {       |  |  |  |
| 60       | 3Ch                        | ,<br><  | 92       | 5Ch        | L<br>\  | 124                 | 7Ch        | l<br>I  |  |  |  |
| 61       | 3Dh                        | =       | 93       | 5Dh        | ì       | 125                 | 7Dh        | }       |  |  |  |
| 62       | 3Eh                        | >       | 94       | 5Eh        | 7       | 126                 | 7Eh        | ~       |  |  |  |
| 63       | 3Fh                        | ?       | 95       | 5Fh        |         |                     |            |         |  |  |  |
|          |                            | •       |          |            | -       | theASCIIcode.com.ar |            |         |  |  |  |



## Entering the student ID, and display your name.

- Objective: Display corresponding name after entering student ID.
- Hint:
- 1. Don't use function RETARGET\_Configuration() and scanf().
- 2. Tera Term enable "local echo".
- 3. Follow code example on the next page.

☆ PS. Please record.

```
uc8 gHelloString[] = "Hello, this is USART Tx/Rx interrupt example. Please enter your student ID...\r\n";
u8 gTx_Buffer[128];
u8 gRx_Buffer[128];
u8 studentID1[] = """; Declaration of member1's student ID array.
u8 studentID2[] = """; Declaration of member2's student ID array.
```

```
void UxART RxTest(void)
 u32 i;
 u32 uLength;
  /* Waiting for receive 5 data
 if (gURRx_Length >= 1) length of student numbers
   // Process Rx data by gRx_Buffer[] and gURRx_Length here
   // .....
    uLength = gURRx Length;
    for (i = 0; i < uLength; i++)
      gTx Buffer[i] = gRx Buffer[i];
      if(gTx Buffer[i] == studentIDl[i])
        The last element of the array "gTx_Buffer[i]" \ " studentID1[i]"
          printf("\r\n My name is
      }else if(gTx Buffer[i] == studentID2[i]) {
   if(i==) { The last element of the array "gTx_Buffer[i]" ` " studentID2[i]"
          printf("\r\n My name is
     }else{
      printf("\r\nERROR\r\n");
      break;
   #if 1 // Loop back Rx data to Tx for test
   gURTx Ptr = (u8 *)gHelloString;
   gURTx Length = sizeof(gHelloString) - 1;
   USART IntConfig(HTCFG UART PORT, USART INT TXDE | USART_INT_TXC, ENABLE);
   #endif
   gURRx Length = 0;
```

# Class Dismissed